




































List of stitch patterns

-  : Types of patterns that can be selected under the single mode
-  : Types of patterns that can be selected under the combination mode
-  : Patterns that can be sewn with the "JUKI Smart Feed"

Practical	Buttonhole	Appliqué	Tapering	Quilt line	Scallop
<p>001 002 003 004 005</p>  <p>006 007 008 009 010</p>  <p>011 012 013 014 015</p>  <p>016 017 018 019 020</p>  <p>021 022 023 024 025</p>  <p>026 027 028 029 030</p>  <p>031 032 033 034 035</p>  <p>036 037 038 039 040</p>  <p>041 042 043 044</p> 	<p>101 102 103 104 105</p>  <p>106 107 108 109 110</p>  <p>111 112 113 114 115</p>  <p>116 117 118 119 120</p>  <p>121 122</p> 	<p>201 202 203 204 205</p>  <p>206 207 208 209 210</p>  <p>211 212 213 214 215</p>  <p>216 217 218 219 220</p>  <p>221 222 223 224 225</p>  <p>226 227 228 229 230</p>  <p>231 232 233 234 235</p>  <p>236 237 238 239 240</p> 	<p>301 302 303 304 305</p>  <p>306</p> 	<p>401 402 403 404 405</p>  <p>406 407 408 409 410</p>  <p>411 412 413 414 415</p>  <p>416 417 418 419 420</p>  <p>421 422</p> 	<p>501 502 503 504 505</p>  <p>506 507 508 509 510</p>  <p>511 512</p> 

* The listing can be found inside the top cover of the sewing machine.

One-point	Decorative	Vintage	Feather / Lace
601 602 603 604 605	701 702 703 704 705	746 747 748 749 750	801 802 803 804 805
606 607 608 609 610	706 707 708 709 710	751 752 753 754 755	806 807 808 809 810
611 612 613 614 615	711 712 713 714 715	756 757 758 759 760	811 812 813 814 815
616 617 618 619 620	716 717 718 719 720	761 762 763 764 765	816 817 818 819 820
621 622 623 624 625	721 722 723 724 725	766 767 768 769 770	821 822 823 824 825
626 627 628 629 630	726 727 728 729 730	771 772 773 774 775	826 827 828 829 830
631 632 633 634 635	731 732 733 734 735	776 777 778 779 780	831 832 833 834 835
636 637 638 639 640	736 737 738 739 740	781 782 783 784 785	836 837
641 642 643 644 645	741 742 743 744 745	786	

Letters / numbers / signs

A B C D E	A B C D E	A B C D E	A B C D E	あ い う え お
F G H I J	F G H I J	F G H I J	F G H I J	か き く け こ
K L M N O	K L M N O	K L M N O	K L M N O	さ し す せ そ
P Q R S T	P Q R S T	P Q R S T	P Q R S T	ア イ ウ エ オ
U V W X Y	U V W X Y	U V W X Y	U V W X Y	カ キ ク ケ コ
a b c d e	a b c d e	a b c d e	a b c d e	サ シ ス セ ソ
f g h i j	f g h i j	f g h i j	f g h i j	一 二 三 四 五
k l m n o	k l m n o	k l m n o	k l m n o	六 七 八 九 十
p q r s t	p q r s t	p q r s t	p q r s t	幼稚園 保育園
u v w x y	u v w x y	u v w x y	u v w x y	小学校 年組
1 2 3 4 5	1 2 3 4 5	1 2 3 4 5	1 2 3 4 5	一 ~ . ! ?
6 7 8 9 0	6 7 8 9 0	6 7 8 9 0	6 7 8 9 0	あ い う え お
Ä Å Æ à ä	Ä Å Æ à ä	Ä Å Æ à ä	Ä Å Æ à ä	か き く け こ
á è é ê ë	á è é ê ë	á è é ê ë	á è é ê ë	さ し す せ そ
Ç ç Ì Ñ ñ	Ç ç Ì Ñ ñ	Ç ç Ì Ñ ñ	Ç ç Ì Ñ ñ	ア イ ウ エ オ
ñ Ö Ø ò ö	ñ Ö Ø ò ö	ñ Ö Ø ò ö	ñ Ö Ø ò ö	カ キ ク ケ コ
ø Û ù ü	ø Û ù ü	ø Û ù ü	ø Û ù ü	サ シ ス セ ソ
. , : ; ?	. , : ; ?	. , : ; ?	. , : ; ?	一 二 三 四 五
				幼稚園 保育園
				一 ~ . ! ?